

# Super Wolverine Instructions.

Your Super wolverine is shipped to you with the Carbon in a separate container to prevent shipping damage. To install the carbon simply remove the plug from the top of the filter and fill the filter housing to the top. Do not "Pack" the carbon in, however you may shake the filter slightly to settle the carbon naturally.

Once the filter is filled replace the plug. (The plug only needs to be hand tight)

Install the filter on your vent and enjoy.



## Simple Solutions Dist LLC

6 Jacobs Road

West Milford NJ 07480

Phone: 973 846 7817

Toll Free: 1-866-667-8465

Email:

[SimpleSolution1@optonline.net](mailto:SimpleSolution1@optonline.net)

[WWW.stopsepticodor.com](http://WWW.stopsepticodor.com)

